



# Wireless Mouse 2.4G

# Wireless Mouse 2.4G

### Wireless Mouse 2.4G

# PRODUCT FEATURE

- 1. 2.4G working frequency, Strong versatility, transmission distance up to
- 10 meters.

  2. Using the low-power chip KA8G2, the mouse consumes less power and the battery lasts longer.

  3. 800/1200/1600/2400/4000 five-speed CPI switching function and CPI
- gear indicator, switch the speed you like at will.

  4. Support multi-level power saving mode switching, save battery energy
- to the maximum.

- to the maximum.
  5. Low battery reminder function.
  6. Ultra-micro (Nano) receiver, plug and play.
  7. Support Windows98SE/ME/2000/XP/Vista/Win7/Win10/Win11/Mac10.x and other operating systems. ERPORT

# BUTTON FUNCTION





- - 1 Mouse Wheel Left Button
     Right Button
  - Forward Button

  - Backward Button
     CPI Switch Button

  - (7) Receiver
  - Battery compartment

### HOW TO USE

- 1. Take out the mouse, and place an AA battery with correct polarity into the
- 2. Take out the receiver in the bottom of mouse and plug into the computer USB connector.
- The driver will be installed automatically for your usage.

### CPI ADJUSTMENT

With 5-Level CPI Adjustment 800/1200/1600/2400/4000, default CPI is 1200. Press the CPI button and the specific CPI LED will flash.

# ADJUST THE MOUSE RETURN RATE

Press and hold the middle and right buttons of the mouse for about 3 seconds, and the mouse return rate will switch between 125Hz and 250Hz. When switched to 125Hz, the red LED under the mouse wheel will flash slowly 3 times, and when switched to 250Hz, the red LED under the mouse wheel will flash quickly 3 times

## AUTOMATIC SLEEP

If you do not use the mouse after parking, it will enter sleep mode. You can wake it up by pressing a button or moving the mouse (you need to press a button to wake it up after parking for about 8 minutes)

# LOW BATTERY REMINDER

When the battery of the mouse is low, the red LED under the mouse wheel will flash during the use of the mouse. Please replace the battery in time

# RECEIVER COLLECTION FUNCTION

- The ultra-micro (Nano) receiver can be placed in the storage socket at the bottom of the mouse, which is convenient for carrying out to avoid missing.
- Due to some special reasons, such as high temperature, high magnetic field, etc., the wireless mouse and the receiver may lose normal connection and need to be reconnected before use.

  ①Unplug the receiver and then plug it back in.
- ②Keep the distance between the mouse and the receiver at 30CM, remove the battery and re-insert it, and you can use the wireless mouse again

# CAUTIONS

- In wireless mode, the data transmit by 2.4GHz radio waves, the linear using distance is up to 10 meters, which could be reduced if there are large obstacles or environmental interference.
- The performance of the mouse may also affected by uneven, reflective deskton

# PACKAGE CONTENT

1\*2.4G Wireless Mouse / 1\*USB Receiver / 1\*User Manual

# BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

- DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic
- DO NOT touch the battery fi material is leaking and seek immediate medical
- Tatention if any material comes into contact with your skin or eyes.

  DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

  DO NOT remove the battery except for proper disposal and recycling as
- required by local laws and regulations.

  DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harimful.

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

